

COMPONENTS	
A1	CONTROLLER NINEPWA-PREMIUM-01
A2	CONTROLLER EPWA-PREMIUM-RLPP-01
C1,C2,C3	EMC FILTER
F1	DC POWER FUSE
F2,F3,F4,F5	THERMAL PROTECTIONS
H1, H2	LAMPS
H3	TEMP. BATT PROBE (option)
K1	CONTACTOR
K2	CONTACTOR (water refill - option)
K3, K4	CONTACTOR (LAMPS)
L1,L2,L3	AC MAINS
PE	GROUND
S1	F1 KEY
S2	F2 KEY
S3	STOP PUSHBUTTON
S4	LEFT KEY
S5	RIGHT KEY
T1	POWER TRANSFORMER
T2	AUX TRANSFORMER
X5	BATTERY PLUG
V1	RECTIFIER
Z1	VARISTOR

